

FEATURES AND SPECIFICATIONS.

REMOTE ENGINE START SYSTEM II

CLIMATE CONVENIENTLY CONTROLLED.

AT YOUR FINGERTIPS

The remote engine starter will automatically set the car's interior temperature to 22° C regardless of the last A/C setting. On days when it's hotter than 7.5° C (45.5° F), it will automatically turn the air conditioner on in the AUTO mode. When ambient temperature is lower than 7.5C (45.5F), the windshield defroster mode is automatically set and the rear defogger/heated door mirror is turned on.

The car's interior temperature can easily be determined by simply looking at the remote's easy to read LCD display, when engine is running with the remote engine starter. The power to harness the elements is not only in your hands, it's at your fingertips.



Remote Communication	2-Way LCD
Remotes *	1 Remote
Range	Up to 120 meters
In-car Temperature Feedback	•
Security	•
Keyless Entry	•
Trunk Release	•
Panic Button	•
Reception Feedback	•
System Check	•
Run-time	10 or 20 mins
Automatic Climate Control	•
Keyless Memory Seating **	•

* One additional remote is available for purchase.

** Only on vehicles equipped with this feature.



GENUINE ACCESSORIES



GENUINE ACCESSORIES




Call 1-888-9ACURA9 for the Dealer nearest you.
Visit www.acura.ca.

GET OFF TO A COMFORTABLE START WHEN THE WEATHER OUTSIDE ISN'T.

Now you can get off to a good start before you even get started with the Remote Engine Start System II. It enables you to start your vehicle from up to 120 meters away before going outside in the cold or heat. The remote can conveniently be used to lock and unlock the doors as well as the trunk while the specially designed wiring harness seamlessly integrates your immobilizer and security system to ensure your vehicle's protection. And there is no wire splicing necessary.

CHECK VEHICLE'S CONDITION



*Only on vehicles equipped with the Memory Seat feature

ADDITIONALLY

The Remote Engine Start System II carries a 4-year/80,000 km warranty when installed in your new vehicle at the time of purchase.


THE LUXURIES OF LIFE MADE SAFE.



The Acura Remote Engine Start System II has a number of built-in features to ensure your safety at all times:

- ☺☺ Car doors remain locked while engine is warming up
- ☺☺ To avoid accidental operation, there are two buttons that must be pressed consecutively to start and stop the engine
- ☺☺ Integrated into the vehicle security system for vehicle protection
- ☺☺ In order to reduce carbon-monoxide build-up, there is a maximum of two consecutive starts with the remote

* If in an open area, a range up to 450 meters may be achieved.



EASY TO UNDERSTAND STATUS ICONS.

- Transmitter Is Communicating
- Transmitter Cannot Communicate With Vehicle
- System Checking Status
- Engine Is Running
- Engine Is Stopping
- Idling Remaining Time
- Inside Car Temperature Range*
- Memory Seat Application**
- Door Lock Is On Unlock Position
- Door Or Trunk/Tailgate Is Open
- Hood Is Open
- Ignition Key Is Inside Vehicle For Smart Start Vehicles Or On
- Panic Alarm Has Been Triggered
- Continuous Start Inhibition Mode
- Shifter Is Not In Park Position

* For vehicles equipped with Auto A/C.

** Feature available only for vehicles equipped with Memory Seat feature.